



# **HL-PA085-L02** Installation instruction


### suspended installation




① Drilling holes in the ceiling.



③ Screw one end of the hanging rope splitter into the T-nut on the lamp, and screw the other end of the hanging rope into the ceiling to lock it.




② Insert the plastic wall plug into the hole and lock the fixed end of the sling.




4 Bundle the input line and the hanging rope together and connect to the mains electricity.


### magnetic surface mounting




① Drilling holes in the ceiling.



② Insert the plastic wall plug into the hole and lock the iron sheet and the secure steel wire rope.




3 Lock the secure steel wire rope under the magnet.





(5) Access to mains electricity


# Spliceable

First, put the lamps together, and then insert the H-shaped profile strips into the slots; To fix it, insert the connecting piece between the two lamps, and then lock the screws with a small wrench.









#### **Notices**

- 1. The power supply must be turned off before installation.
- 2. Make sure the product is mounted under the surface of the object to be installed, and finally turn on the power to light up.
- 3. This product is for indoor use only.
- 4. This product is warranted for 3 years and problems occur within 3 years (except for human factors and accidental factors), free maintenance.
- 5.The product is not responsible for damage caused by accidental factors or improper use.